


English

HOW TO USE THE DOORBELL

Push the button on the transmitter. The receiver receives the signal and will play the presetted sound.




RECEIVER - PAIRING WITH TRANSMITTER

- 1) Hold the receiver's pairing button for 3 seconds until you here hear the "Ding-Dong" sound.
- 2) Press the transmitters push button to pair the transmitter and receiver.
- 3) The receiver will play the "Ding-Dong" sound to confirm the pairing is confirmed.

français

COMMENT UTILISER LA SONNETTE

Appuyez sur le bouton de l'émetteur. Le récepteur reçoit le signal et jouera le son pré réglé.



RÉCEPTEUR - JUMELAGE AVEC L'ÉMETTEUR

- 1) Maintenez le bouton de couplage du récepteur enfoncé pendant 3 secondes jusqu'à ce que vous entendiez le son «Ding-Dong».
- 2) Appuyez sur le bouton-poussoir de l'émetteur pour jumeler l'émetteur et le récepteur.
- 3) Le récepteur joue le son «Ding-Dong» pour confirmer que le couplage est confirmé.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carton-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity.
- Do not short-circuit the supply terminal.
- Remove batteries when not in use. Recycle or dispose of exhausted batteries according to local laws. Do not dispose of batteries in a fire – they may leak or explode.

KEEP THIS INSTRUCTION MANUAL FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

FOR QUESTIONS OR SUPPORT PLEASE CONTACT US AT:

NL / EN - support@alleenonline.nl

BE / FR - support@alleenonline.be

Nederlands

HOE DE DEURBEL TE GEBRUIKEN

Druk op de knop op de zender. De ontvanger ontvangt het signaal en speelt het vooraf ingestelde geluid af.




ONTVANGER - KOPPELEN MET DE VERZENDER

- 1) Houd de koppelknop van de ontvanger 3 seconden ingedrukt totdat u het "Ding-Dong" -geluid hoort.
- 2) Druk op de drukknoop van de zender om de zender en ontvanger te koppelen.
- 3) De ontvanger speelt het "Ding-Dong" -geluid af om te bevestigen dat de koppeling is gelukt.

Deutsche

SO VERWENDEN SIE DIE KLINGEL

Drücken Sie die Taste am Sender. Der Receiver empfängt das Signal und gibt den voreingestellten Ton wieder.



EMPFÄNGER - PAARUNG MIT SENDER

- 1) Halten Sie die Pairing-Taste des Receivers 3 Sekunden lang gedrückt, bis Sie hier den „Dong-Dong“ -Ton hören.
- 2) Drücken Sie die Sendertaste, um Sender und Empfänger zu koppeln.
- 3) Der Receiver gibt den "Dong-Dong" -Ton aus, um zu bestätigen, dass das Pairing bestätigt wurde.

RoHS  

© 2020The Investment Company Europe B.V.

Hyundai logos are trademarks of Hyundai Corporation, Korea.

Licensed to The Investment Company Europe B.V. All rights reserved.

Distributed by The Investment Company Europe B.V. Exclusively developed for sales in Belgium, the Netherlands and Luxembourg.

PATENT PENDING

The artwork and design of this package are protected by European copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, or reproduce any trademarks or copyright notice from this package.

Licensed by Hyundai Corporation, Korea